

SPEAKER MOUNTING BRACKETS

WCB-12 (BLACK)
WCB-12W (WHITE)

1. SAFETY PRECAUTIONS

- Be sure to read the instructions in this section carefully before use.
- Make sure to observe the instructions in this manual as the conventions of safety symbols and messages regarded as very important precautions are included.
- We also recommend you keep this instruction manual handy for future reference.

• Symbols

Caution action	Prohibited action
	
Caution	Prohibition



WARNING

Indicates a potentially hazardous situation which, if mishandled, could result in death or serious personal injury.

Install the mounting bracket only in a location that can structurally support the weight of the speaker and the mounting bracket. Doing otherwise may result in the speaker falling down, causing personal injury and/or property damage.



Caution



CAUTION

Indicates a potentially hazardous situation which, if mishandled, could result in moderate or minor personal injury, and/or property damage.

Do not stand or sit on, nor hang down from the mounted speaker as this may cause it to fall down or drop, resulting in personal injury and/or property damage.



Prohibition

2. GENERAL DESCRIPTION

These TOA speaker mounting brackets are designed for indoor use exclusively with the F-10 and F-160 series speaker systems to mount them on a wall or ceiling. Speaker angle can be changed freely to your desirous direction according to the speaker location.

3. NOMENCLATURE AND INSTALLATION


3.1 Procedures

1. Mount the bracket base to a wall or ceiling.
Verify that the wall or ceiling can safely support the weight of both the speaker mounting bracket and mounted speaker, and reinforce if its strength is insufficient.

Note

No screws are supplied for mounting the bracket base to a wall or ceiling.
Prepare the commercial screws appropriate for the wall or ceiling material.

2. Fix the speaker to the suspension bracket with the supplied two M5 speaker mounting screws.
3. After turning the speaker towards your desirous direction, tighten the angle adjustment screw securely.




Cautions


- After mounting, verify that each screw is tightened securely.
- * Never loosen the hexagon socket head safety screw for falling-out prevention.

3.2 Mounting Examples of the F-160 Series Speaker Systems

- When mounting the speaker to a ceiling



- When mounting the speaker to a wall



4. SPECIFICATIONS

Model	WCB-12	WCB-12W
Applicable speaker	F-10 and F-160 series speaker systems	
Load limit of speaker	4 kg or less	
Finish (painting)	Black	White
Weight	0.6 kg	
Accessories	Speaker mounting screw x 2 Plain washer x 2 Instruction manual x 1	

Note: Specifications are subject to change without notice.